



MODEL 76079
For 1 player / Ages 8 and up
INSTRUCTION MANUAL
 P/N 823-A6800-106 Rev.A

I KNOW WHAT YOU'RE THINKING!

I've focused my artificial intelligence on Music and Sports and I know everything about rock and pop songs, singers, bands, sports heroes, teams, venues and much more. Think of any topic and answer my questions. Answer the questions honestly, and I will tell you what you're thinking!

BUTTONS AND FEATURES

Press to increase speed of text and move backward through text

Press to decrease speed of text and move forward through text



ON/YES/NEW GAME – Press this button to turn the unit ON. This button will also allow you to answer YES to a question or prompt. To start a NEW GAME, press and hold this button until the unit clears and a new game begins.

NO – Use this button to answer “NO” to a question.

SOMETIMES – Press this button to answer “depends” or “maybe” to a question or prompt.

RARELY – Press this button if the question or prompt “seldom” or “hardly ever” applies.

UNKNOWN – Press this button if the question is irrelevant or if the answer is UNKNOWN.

UNDO – This button will allow you to change your previous answer by going back to the prior question.

SOUND – Press this button to turn the sound ON or OFF. A high tone indicates SOUND is ON, a low tone indicates when the sound has been turned OFF.

SCROLL BUTTONS – Use these two buttons to move forward or backward through the menu, or to return to a previous section. Also, press the

E

LEFT SCROLL button to increase the speed of the scrolling text, and press the RIGHT SCROLL button to slow it down.

RESET – If the game begins to malfunction, insert a blunt point and press the RESET button. This action will RESET the game to its original settings.

SLEEP MODE – After 60 seconds of inactivity, the game will automatically shut down, going into SLEEP MODE. To turn it on again, simply press the ON button and the game will start where you ended play.

LET'S BEGIN

Although you won't win, I'll tell you how to play anyway!

Press the ON button to turn the unit on or wake the unit from SLEEP MODE. To start a new game, press and hold the NEW GAME button until the current game clears. You will be asked if you would like to play 20Q Music. If you press YES, a game of 20Q Music will begin. If you press NO, you will be asked if you would like to play 20Q Sports. Once you decide which game you would like to play, think of anything related to that topic. I will ask if you are READY to play. If you're ready, press the YES button to begin.

I will ask you a series of questions before I guess what you're thinking. However, I will always begin with the same set of questions: Are you a Person, Place, Thing or Unknown? There are two ways to answer the first four questions. First, you can answer each question with YES or NO as I advance to the next question. Or, you can toggle between these four questions by pressing the LEFT SCROLL or RIGHT SCROLL buttons to identify the question that is correct and answer YES.

When I ask the remaining questions, answer honestly by pressing one of the answer buttons (YES, NO, SOMETIMES, RARELY, UNKNOWN). If you answered a question incorrectly, press the UNDO button to return to the prior question. I will try to guess what you are thinking before I have asked 20 questions. However, I may ask you a total of 20 questions. At this point, I will try to guess what you're thinking. If I guess correctly, press the YES button. If for some strange reason I guess incorrectly, I will ask you five more questions than guess again.

When I guess what you are thinking, I win! If all my guesses are wrong, you win. But don't worry, that will never happen.

Good luck! You're going to need it!

BATTERY INSTALLATION

This game is powered by two (2) AAA (LR03) batteries.

- Using a screwdriver, loosen the screw until the battery compartment door can be removed.
- Insert two (2) AAA (LR03) batteries (we recommend alkaline) as indicated inside the battery compartment.
- Replace the battery compartment door and tighten the screw with a screwdriver. Do not over-tighten.

ADULT SUPERVISION IS RECOMMENDED WHEN CHANGING BATTERIES.

CAUTION

- **As with all small batteries, the batteries used with this device should be kept away from small children who might still put things in their mouths. If a battery is swallowed, consult a physician immediately.**

- **Be sure you insert the battery correctly and always follow the device and battery manufacturer's instructions.**
- **Do not dispose of batteries in fire.**
- **Batteries might leak if improperly installed, or explode if recharged, disassembled or heated.**
- **Sometimes, a build-up of static electricity (from carpets, etc) may cause the game to stop working. Just reset the game, and it will work again.**
- **In an environment with radio frequency interference, the product may malfunction and require user to reset the product.**

MAINTENANCE

- Handle this device carefully.
- Store this device away from dusty or dirty areas.
- Keep this device away from moisture or extreme temperature.
- Do not disassemble this device. If a problem occurs, press the Reset button, or remove and replace the batteries to reset the device, or try new batteries. If problems persist, consult the warranty information located at the end of this instruction manual.
- Use only the recommended battery type.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- Do not use rechargeable batteries.
- Do not attempt to recharge non-rechargeable batteries.
- Remove any exhausted batteries from the device.
- Do not short-circuit the supply terminals.
- Insert batteries with the correct polarity.

Please retain this for future reference.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.

RECYCLING - EUROPE

The consumer has a significant role to play in reducing the impact of waste electrical and electronic equipment on the environment, through re-using or recycling such equipment.

The crossed out wheellie-bin symbol on this product is to remind you that Waste Electrical and Electronic products should not be disposed of with household waste. If you are unable to re-use or recycle your product it should be disposed of at a civic amenity site.

While Radica toys comply with all relevant safety standards, we are obliged to tell you that some of the components used in electrical and electronic equipment may contain hazardous substances that can damage the environment and present a risk to human health if not properly disposed of.

90-DAY LIMITED WARRANTY

(This product warranty is valid in the United States and Canada only)

Radica Games Limited warrants this product for a period of 90 days from the original purchase date under normal use against defective workmanship and materials (batteries excluded). This warranty does not cover damage resulting from accident, unreasonable use, negligence, improper service or other causes not arising out of defects in material or workmanship. Radica Games Limited will not be liable for any costs incurred due to loss of use of this product or other incidental or consequential costs, expenses or damages incurred by the purchaser. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations may not apply to you. This warranty gives you specific legal rights and you may also have other legal rights, which vary from state to state.

During this 90-day warranty period, the game will either be repaired or replaced (at our option) without charge to the purchaser when returned prepaid with proof of date of purchase to: Radica USA, Ltd., 13628-A Beta Road, Dallas, Texas 75244, USA. Please remove the batteries and wrap the unit carefully before shipping. Please include a brief description of the problem along with your return address and mail it postage prepaid.

IMPORTANT: Before returning the unit for repair, test it with fresh alkaline batteries. Even new batteries may be defective or weak and low battery power is a frequent cause of unsatisfactory operation.

Distributed by:
RADICA USA Ltd.
 13628-A Beta Road
 Dallas, TX 75244-4510



Play on-line at www.20Q.net. Marketed under license from 20Q.net, Inc. All rights reserved.

RADICA: ®
 20Q AND "I CAN READ YOUR MIND"
 ARE TRADEMARKS OF 20Q.NET, INC.
 USED UNDER LICENSE BY RADICA GAMES LTD.
 © 2006 RADICA GAMES LTD.
 PRODUCT SHAPE™
 ALL RIGHTS RESERVED

None of the persons, places, bands, teams, events or other answers have sponsored or endorsed this game in any way.